

FANUC 10/100 series

FANUC 11/110 series

FANUC 12/120 series

OPERATOR'S MANUAL
(APPENDIXES)

B-54810E

B - 54810E/ 01

FANUC LTD, 1986

This manual describes the following products:

Name of products	Abbreviation		
FANUC 10T-MODEL A	10T-A	10T	10 series
FANUC 10T-MODEL F	10T-F		
FANUC 10M-MODEL A	10M-A	10M	
FANUC 11T-MODEL A	11T-A	11T	11 series
FANUC 11TT-MODEL A	11TT-A	11TT	
FANUC 11TT-MODEL F	11TT-F		
FANUC 11M-MODEL A	11M-A	11M	
FANUC 11M-MODEL F	11M-F		
FANUC 12T-MODEL A	12T-A	12T	12 series
FANUC 12M-MODEL A	12M-A	12M	

APPENDIX 1. FUNCTIONS AND TAPE FORMAT LIST
APPENDIX 2 RANGE OF COMMAND VALUE
***A*PPENDIX 3**
APPENDIX 4 TAPE JOINING
APPENDIX 5 STATUS WHEN TURNING THE POWER ON, WHEN RESET
APPENDIX 6 PARAMETERS

- **1. Parameter Display**
- **2. Parameter Setting**
- **3. Parameter Tape Punch**
- **4. Descriptions of Parameters**

APPENDIX 7 CODES USED IN PROGRAM
***A*PPENDIX 8 LIST OF INTERNAL CODES OF *K*ANJI AND HIRAGANA**
APPENDIX 9 G CODE TABLE
APPENDIX 10 ERROR CODE TABLE
APPENDIX 11 WARNING MESSAGE LIST
APPENDIX 12 LIST OF OPERATIONS
APPENDIX 13 LIST OF SPECIFICATIONS